





SPARE PARTS EXPLODED VIEW GAS-WALL BOILER ATM. BURNER

Model





MICROSYSTEM 21-28 RFFI

R8217932-01 - 19/07/2017

1	537006	MicroSystem 21 RFFI met. ARISTON	07-2002	12-2005
2	537010	MicroSystem 28 RFFI met. ARISTON	07-2002	12-2005
3	537014	MicroSystem 21 RFFI met. RADI	07-2002	02-2006
4	537018	MicroSystem 28 RFFI met. RADI	07-2002	02-2006
5	537022	MicroSystem 21 RFFI met. SIMAT	07-2002	06-2006
6	537026	MicroSystem 28 RFFI met. SIMAT	07-2002	06-2006
Col	Reference	Model type	Begin	End



				MICR- 21 RFFI (AR) MICR- 28 RFFI (AR) MICR- 21 RFFI (RD) MICR- 28 RFFI (RD) MICR- 21 RFFI (SM) MICR- 28 RFFI (SM)																			
	Description	Manf. Pt. N	Type																			31	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	From	to
0002	EXPANSION VESSEL 6L	998616		●	●	●	●	●	●														
0003	BUSH (EXPANSION VESSEL)	998776		●	●	●	●	●	●														
0004	LOCK NUT 3/8"	998581		●	●	●	●	●	●														
0005	FRAME SUPPORT	65100295		●	●	●	●	●	●														
0006	GASKET 3/8"	573521		●	●	●	●	●	●														
0007	PIPE (EXPANSION VESSEL)	999525		●	●	●	●	●	●														
0008	O-RING	998077		●	●	●	●	●	●														
0009	CABLE HOLDER	998580		●	●	●	●	●	●														
0011	SPRING (FASTENING)	570717		●	●	●	●	●	●														
0012	PIVOT	995492		●	●	●	●	●	●														
0013	GASKET 3/4"	573520		●	●	●	●	●	●														
0015	THERMOSTAT (ANTI-FROST)	570760		●	●	●	●	●	●														
0016	FIXING SPRING (THERMOSTAT)	999557		●	●	●	●	●	●														
0017	UNION BY-PASS + O-RING	65102068		●	●	●	●	●	●														
0018	BY-PASS	996046		●	●	●	●	●	●														
0019	FLOW GROUP	996049		●	●	●	●	●	●														
0020	GASKET 1/2"	573528		●	●	●	●	●	●														
0021	CABLE (LOW WATER PRESSURE SWITCH)	995407		●	●	●	●	●	●														
0022	SAFETY VALVE	998447		●	●	●	●	●	●														
0023	GASKET 1/4	569390		●	●	●	●	●	●														
0024	LOW PRESSURE SWITCH	995903		●	●	●	●	●	●														
0025	SPARK GENERATOR (KIT)	65100514		●	●	●	●	●	●														
0026	GASKET (SPARK GENERATOR)	574279		●	●	●	●	●	●														
0027	GAS VALVE	65102349		●	●	●	●	●	●														
0028	COMPENSATION TUBE	573576		●	●	●	●	●	●														
0029	DRAIN VALVE	998809		●	●	●	●	●	●														
0030	RETURN GROUP	990708		●	●	●	●	●	●														
0031	O-RING	998424		●	●	●	●	●	●														
0032	PUMP BRACKET	999162		●	●	●	●	●	●														
0033	KIT FOR REAR PUMP ATTACHMENT	996614		●	●	●	●	●	●														
0034	LOCK WASHER	999100		●	●	●	●	●	●														
0036	CABLE (PUMP)	995906		●	●	●	●	●	●														
0037	SPRING (PUSH BUTTON)	999603		●	●	●	●	●	●														
0038	PUSH BUTTON	999469		●	●	●	●	●	●														
0039	SPINDLE (PUSH BUTTON)	999442		●	●	●	●	●	●														
0040	RESET BUTTON INSERT	999444		●	●	●	●	●	●														
0041	L.E.D. (POWER INDICATOR)	997714		●	●	●	●	●	●														
0042	CONTROL KNOB	999456		●	●	●	●	●	●														
0043	CONTROL PANEL (FRONT)	999459		●	●	●	●	●	●														
0045	THERMOSTAT (REGULATION)	999577		●	●	●	●	●	●														
0046	EARTH CABLE (P.C.B.)	999547		●	●	●	●	●	●														
0047	NYLON BUSH (10MM)	569711		●	●	●	●	●	●														
0048	PRINTED CIRCUIT BOARD (CB3-FFI02)	65101255		●	●	●	●	●	●														
0049	PRESSURE GAUGE	65100695		●	●	●	●	●	●														
0053	TERMINAL BOARD	995473		●	●	●	●	●	●														
0055	U-CLIP	571548		●	●	●	●	●	●														
0056	O-RING	998517		●	●	●	●	●	●														
0058	GASKET (ADHESIVE - 14X6 MM)	65102772		●	●	●	●	●	●														
0059	Y PIECE (AIR PRESSURE)	573327		●	●	●	●	●	●														
0060	AIR PRESSURE SWITCH 53 Pa	995291-01		●		●		●															
	AIR PRESSURE SWITCH 96 Pa	571653-01			●		●		●														
0061	AIR INTAKE COVER	573329		●	●	●	●	●	●														
0062	SUPPORT PLATE	997203		●	●	●	●	●	●														
0064	COVER (FLUE TEST POINT)	998565		●	●	●	●	●	●														
0065	GASKET (FLUE TEST POINT)	998636		●	●	●	●	●	●														
0066	RESTRICTOR (D=41)	995315			●		●		●														
	RESTRICTOR D=46	65101023		●		●		●															
0067	FLUE (EXHAUST MANIFOLD / HEADER)	999561		●	●	●	●	●	●														
0068	GASKET (FLUE COLLAR)	998637		●	●	●	●	●	●														
0069	PLUG (AIR INTAKE)	998595		●	●	●	●	●	●														
0070	EARTH CABLE (FAN)	999925		●	●	●	●	●	●														
0071	CABLE (SEALED CHAMBER)	999548		●	●	●	●	●	●														
0072	PANEL (INSULATION - FAN)	999135		●	●	●	●	●	●														
0073	FIXING CLAMP (FAN)	998566		●	●	●	●	●	●														
0074	GASKET (FAN)	65100707		●	●	●	●	●	●														
0075	FAN	998894			●		●		●														
	FAN	999489		●		●		●															
0076	PANEL (INSULATION - REAR)	998640		●		●		●															
	PANEL (INSULATION - REAR)	999554			●		●		●														
0077	PANEL (L.H. SIDE)	995893		●		●		●															



Gas-wall boiler atm. burner

The indications mentioned on the prices, commercial or technical literature and the scheme are written for your guidance and are available at a given time. The CONSTRUCTOR retains the power to modify the presentation, the form, the size, the conception or the material of the products.